

Data teknis

Fluke TRM50 Coaxial Feed-through BNC Male to BNC Female Cable Terminator



Ikhtisar Produk: Fluke TRM50 Coaxial Feed-through BNC Male to BNC Female Cable Terminator

Terminator Kabel TRM50 Coaxial Feed-through BNC Male ke BNC Female

Spesifikasi: Fluke TRM50 Coaxial Feed-through BNC Male to BNC Female Cable Terminator

Spesifikasi	
Impedansi	50 Ohm
Voltase Maks melewati ground	1000V CAT III
Daya maks	1W

Model



Fluke TRM50

Fluke. *Memastikan aktivitas Anda terus berjalan dan beroperasi.*

Fluke Corporation

PO Box 9090, Everett, WA 98206 U.S.A.

For more information call:

In the U.S.A. (800) 443-5853

In Europe/M-East/Africa

+31 (0)40 267 5100

In Canada (800)-36-FLUKE

From other countries +1 (425) 446-5500

www.fluke.com

BUT. FLUKE SOUTH EAST ASIA PTE LTD

Menera Satu Sentra Kelapa Gading #06-05

Jl. Bulevar Kelapa Gading Kav. LA# No. 1

Summarecon Kelapa Gading

Jakarta Utara 14240

Indonesia

Tel: +62 21 2938 5922

Email: info.asean@fluke.com

www.fluke.com/id

©2024 Fluke Corporation. Specifications subject to change without notice.

04/2024

Modification of this document is not permitted without written permission from Fluke Corporation.